

# Overview of Sentaurus

*Advanced multidimensional semiconductor device simulator*

Created by Ian Xuan Xiao ECE1T2+PEY  
(with Z. Rahim & Prof. N. Kherani)  
Modified in 2015 by Prof. J. Poon

# Presentation Outline

- Why use Sentaurus?
- Introduction to Sentaurus
  - introduction to Sentaurus main interface
  - overview of main tools
- Step-by-Step Project Walkthrough


# Why Do We Use Sentaurus ?

- 1) To learn and have the experience of carrying out semiconductor (SC) device designs by using one of the **most advanced software tools** in the industry


Sentaurus allows engineers to design the device to meet performance specifications and to design the fabrication process to make the devices.



Resistor



Transistor




Diode

# Why Do We Use Sentaurus ?

- 2) Use the **visual aids** in Sentaurus to help you better **understand** the device physics and concepts presented in ECE 335
- 3) Through a **better understanding**, you ought to have a better appreciation of the opportunities and challenges in devices.


# Introduction to Sentaurus

## Main Interface




# Introduction to Sentaurus

## Main Interface




# Introduction to Sentaurus

## Main Interface



# Main Sentaurus Tools

## Structure Editor (SDE)



**Purpose:** Edit device definition, structure, and doping profile

**How to use:**


1. Right click **SDE** at tool bar
2. Click “**Edit Input**” and select “**Command**”
3. Edit command lines to make appropriate device structures and properties

Or, edit ***sde\_dvs.cmd*** under project folder



# Main Sentaurus Tools

## Structure Editor: Command Line



### What does it do:


- Defines shapes and dimensions of various regions
- Define electrode placement and specify material
- Define doping profile or distribution
- Define grid points or mesh to solve the structure

# Main Sentaurus Tools

## Visualization: SVisual


**Precision Cuts**– take a cross section of the device and see various values on a particular axis

Select a particular value to show on the diagram



# Main Sentaurus Tools

## Apply Test Conditions: SDevice



**Purpose:** To apply various device physics conditions and bias voltage on the electrodes

### How to use:

1. Right click **SDevice** icon
2. Click “**Edit Input**” and select “**Command**”
3. Edit command lines to define appropriate device structures and properties

Or, edit **sdevice\_des.cmd** under project folder

# Main Sentaurus Tools

## SDevice: Command Line

```
S /nfs/eecg/homes/extgrad/tiuhongg/hgliu_TCAD/ECE_335/ECE_335_project_0/sdevice_des.cmd - sedit
File Edit Format Settings Help
#-----
* Simulate dark/light J-V characteristics of BACH solar cell
*-----
* By default, dark J-V is simulated.
* To simulate light J-V, set light = on

#setdep @previous@

File{
*-Input
  Grid      = "@tdr@"
  Parameter = "@parameter@"
  * Output Files
  Current   = "@plot@"
  Plot      = "@tdrdat@"
  Output    = "@log@"
}

Electrode {
  { Name="electrode_1" Voltage=0.0 }
  { Name="electrode_2" Voltage=0.0 }
}

Physics {
  Temperature=@temp@
  EffectiveIntrinsicDensity( Slotboom )
  Mobility ( DopingDep eHighFieldSaturation hHighFieldSaturation )
  Recombination(SRH(DopingDep))
  AreaFactor = 1e3 * converting current to mA
}

Insert = "PlotSection_des.cmd"
Insert = "MathSection_des.cmd"

Solve{
  NewCurrentFile="init"
  Poisson

  NewCurrentFile=""
  Coupled (Iterations=100) { poisson electron hole }

  Quasistationary (
    InitialStep=4e-2 Increment=1.1 Minstep=1e-3 MaxStep=1e-1
    Goal { Name="electrode_1" Voltage=5 }
    ) {Coupled (Iterations=100) {Poisson Electron Hole}}


  CurrentPlot ( Time = (Range = (0.0 0.2) Intervals=10; Range = (0.2 1.0) Intervals=2
```

What does it do:

- Apply bias voltage at different electrodes
- Modify operating condition like temperature
- Alter simulation algorithm and device physics

# Main Sentaurus Tools

## Probing and graphing: **Inspect**



**Purpose:** Plot and analyze I-V characteristics at selected nodes under desired doping and bias conditions

**How to use:**


1. Right click the block below **Inspect**
2. Select **“Run”**

# Main Sentaurus Tools

## Probing and graphing: **Inspect**


Some useful functions

Select nodes



# Main Sentaurus Tools

## Inspect Tools: Cursor




**Purpose:** Get *specific* values on curve

**How to use:**

1. Select "Curve" -> "Inspect"
2. Check all boxes at the bottom

# Main Sentaurus Tools

## Inspect Tools: Cursor



**Purpose:** Get *list* of values on curve


**How to use:**

1. Select a curve in “**Curve**” box
2. Click “**Curve Data**” in Curve tab on the top




# Project Demonstration

**Goal:** To set up the structure below and investigate its properties with SVisual and Inspect.



# Project Demonstration




## To set up the device:

1. Understand the geometry
2. Set up variables
3. Define substrate region
4. Place contacts
5. Dope the regions

# Project Demonstration

## Setting up the Device: Geometry




- Sentaurus uses 3D Cartesian coordinate system
- Specify shape and start - end coordinates to set up a substrate region

# Project Demonstration

## Setting up the Device: Structural Variables

```
; -----  
; ### Defined Parameters ###  
; -----  
; > Dimensions <  
(define tSub @tncSi@) ; um, thickness of the substrate  
; > others <  
(define node "@node@")  
; -----  
; ### Creating The Structure ###  
; -----  
  
(sdegeo;set-default-boolean "ABA") ; new will replace old  
  
; > n type cSi layer <  
(sdegeo:create-rectangle (position 0 0 0) (position 10 tSub 0) "Silicon" "Subs")
```




# Project Demonstration

## Setting up the Device: Placing Contacts

```
-----  
; ### Placing Contacts  
-----  
; > Electrode 1 <  
(sdegeo:define-contact-set "electrode_1" 4 (color:rgb 1 0 0 ) "solid" )  
(sdegeo:define-2d-contact (find-edge-id (position 5 0 0) ) "electrode_1")  
  
; > Electrode 2 <  
(sdegeo:define-contact-set "electrode_2" 4 (color:rgb 0 1 0 ) "ll" )  
(sdegeo:define-2d-contact (find-edge-id (position 5 tSub 0) ) "electrode_2")  
***
```


- Attach electrodes as connections between device and external environment



# Project Demonstration

## Setting up the Device: Background Doping


```
;-----  
; ### Setting The Doping ###  
;-----  
; > n region constant doping <  
(sdedr:define-constant-profile "Const.Subs" "PhosphorusActiveConcentration" 4.4e15)  
(sdedr:define-constant-profile-region "PlaceCD.Subs" "Const.Subs" "Subs")  
; > n+ region <  
(sdedr:define-gaussian-profile "doping.profile.nplusSi" "PhosphorusActiveConcentration" "PeakPos" 0 "PeakVal" 4.4e17 "StdDev" 0.15 "Gauss" "Length" 0.1)  
; Window Selection  
(sdedr:define-refeval-window "window.nplusSi" "Line" (position 0 0 0) (position 10 0 0))  
; Doping Placement  
(sdedr:define-analytical-profile-placement "place.nplusSi" "doping.profile.nplusSi" "window.nplusSi" "Positive" "NoReplace")
```



# Project Demonstration



## Setting up the Device: N<sup>+</sup> region Doping

```
-----  
; ### Setting The Doping ###  
-----  
;  
; > n region constant doping <  
(sdedr:define-constant-profile "Const.Subs" "PhosphorusActiveConcentration" 4.4e15)  
(sdedr:define-constant-profile-region "PlaceCD.Subs" "Const.Subs" "Subs")  
;  
; > n+ region <  
(sdedr:define-gaussian-profile "doping.profile.nplusSi" "PhosphorusActiveConcentration" "PeakPos" 0 "PeakVal" 4.4e17 "StdDev" 0.15 "Gauss" "Length" 0.1)  
; Window Selection  
(sdedr:define-refeval-window "window.nplusSi" "Line" (position 0 0 0) (position 10 0 0))  
; Doping Placement  
(sdedr:define-analytical-profile-placement "place.nplusSi" "doping.profile.nplusSi" "window.nplusSi" "Positive" "NoReplace")
```



# Project Demonstration

Visualize with Sentaurus Visual




- Pay attention to the scale on the corner to make sure you set up the doping correctly





# Project Demonstration

Confirm doping with Sentaurus Visual Cuts



# Project Demonstration

## Confirming doping with Sentaurus Visual Precision Cut




1. Select "Tools" on menu bar, and "Precision cuts"
2. Choose desired cutting direction, i.e. X direction
3. Enter coordinate, such as x= 5 to cut in center of the device

Notice the cut line is indicated

# Project Demonstration


## Confirming doping with Sentaurus Visual



1. Select "Tools" on menu bar, and "Precision cuts"
2. Choose desired cutting direction, i.e. Y direction
3. Enter coordinate, such as  $y = 0.5$  to cut horizontally across  
(do not cut at  $y = 0$  because it's technically not in the device)


# Project Demonstration

Getting IV Characteristic with Inspect



# Project Demonstration

## Getting IV Characteristic with Inspect





```
S /nfs/eecg/homes/extgrad/liuhonggg/hgliu_TCAD/ECE_335/ECE_335_project_0/sdevice_des.cmd - sedit
File Edit Format Settings Help
-----
* Simulate dark/light J-V characteristics of BACH solar cell
*
* By default, dark J-V is simulated.
* To simulate light J-V, set light = on
#setdep @previous@
File{
*-Input
  Grid      = "@tdr@"
  Parameter = "@parameter@"
  * Output Files
  Current   = "@plot@"
  Plot      = "@tdrdat@"
  Output    = "@log@"
}
Electrode {
  { Name="electrode_1" Voltage=0.0 }
  { Name="electrode_2" Voltage=0.0 }
}
Physics {
  Temperature=@temp@
  EffectiveIntrinsicDensity( $Slotboom )
  Mobility ( DopingDep eHighFieldSaturation hHighFieldSaturation )
  Recombination(SRH(DopingDep))
  AreaFactor = 1e3 * converting current to mA
}
Insert = "PlotSection_des.cmd"
Insert = "MathSection_des.cmd"
Solve{
  NewCurrentFile="init"
  Poisson
  NewCurrentFile=""
  Coupled (Iterations=100) { poisson electron hole }
  Quasistationary (
    InitialStep=4e-2 Increment=1.1 Minstep=1e-3 MaxStep=1e-1
    Goal { Name="electrode_1" Voltage=5 }
    ) {Coupled (Iterations=100) {Poisson Electron Hole}}
  CurrentPlot ( Time = (Range = (0.0 0.2) Intervals=10; Range = (0.2 1.0) Intervals=2)
}
```

Apply bias if necessary

Adjust calculation parameters if needed

# Project Demonstration

## Getting IV Characteristic with Inspect



# FAQ

1. **Takes forever to compile or get output** -> check account storage quota and talk to lab manager
2. **Changes are not updated** -> make sure to re-compile every block you modify  
and wait until all of them turn yellow
3. **Can't compile and it's read only** -> Select "project" on workbench , then "unlock"
4. **Remote access with puTTY and Xming dosen't work** -> Try Cygwin (Net + X11 package)
  - i.) Enter "startxwin" in command window of Cygwin
  - ii. ) Use ssh -Y username@ugXXX.eecg.utoronto.ca